



PLEASE NOTE : ALL 4 METAL INSERTS
NEED TO HAVE CHAMFERED EDGE
TOWARDS OUTSIDE OF DIFF CASE.
IF THE INSERTS ARE NOT INSERTED
CORRECTLY THE DIFF GEARS WILL
BIND AND NOT WORK CORRECTLY.